

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

Why Add A Subwoofer?

Sub-bass frequencies can be considered to be the foundation upon which to build an accurate and dynamic pro audio system. Subwoofers reproduce the lower frequencies that other speakers cannot reach, and they can do it with clarity, punch, and depth. As time passes, music and entertainment styles change and evolve. Today's music and media presentation systems have to deliver performance that will satisfy the audience's elevated expectations. It should be obvious that the coherence, projection, and intelligibility of the midrange and high frequency components must be optimized because so much critical information is found in those ranges. The use of a subwoofer is of equal importance, however, because a sub will help to fill out the lowest musical octaves of sound and provide a more realistic listening experience. It should be mentioned that bass does not need to be overbearing or exaggerated, but rather, it can be a subtle yet important enhancement to almost any style of music or program. Sub bass quality helps to define the musical and emotional impact of a contemporary pro sound system.

The challenge of selecting sound reinforcement subwoofers is made more complicated by the need to balance acoustical considerations with the hard facts of size, scalability, and transportability (if the system is not permanently installed). Bigger boxes can mean more bass, but they must fit on the stage or in the truck. Woofers can be used singly in some situations, but might need to be combined in multiples for larger events. What will be the effect of stacking or hanging more than one or two boxes? If the system is portable, it must be rugged, sized to pack well in the associated vehicle, and equipped with hardware like handles and wheels that facilitate transportation.

Why Do It Yourself?

There are quite a few really good subwoofer systems on the market today that give excellent performance... for a price. It is not uncommon to see pro sound subwoofer enclosures with selling prices of \$3000 or more. Some of these boxes reflect the use of advanced technologies and materials, and complex associated processors, but there are also some tried and true designs available to the custom builder that can offer very effective performance. With a few common tools, a weekend or two of your time, and some elbow grease, Parts Express can show you how to build a sub that will perform like the commercially available ones and save you money.

Why Parts Express?

Parts Express has specialized in supplying speakers and components to both hobbyist speaker builders and manufacturers for over 16 years. We stock one of the largest selections of loudspeakers in the country from name brands like JBL, Eminence, Vifa, Dayton Loudspeaker, Selenium, Peerless, Focal, Audax, Pyle, Pioneer, and more. We are able to offer outstanding values due to our tremendous sales volume, and our technical support before and after the sale is second to none.

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

Building your own subwoofer

Everybody else is doing it, what's the matter- are you scared?

SET A GOAL

What do you have in mind for your subwoofer, what are your expectations? Acoustical performance is certainly something to consider, but size, shape, and of course cost are also factors that are best established before the project goes very far. Although it can be tempting to select the actual subwoofer driver first because of a super special sale price, or it just looked so shiny and menacing in the picture, resist! The size, shape, and type of enclosure can have a big effect on actual subwoofer performance, and driver selection must be based on matching the speaker to the requirements of the box and it's specific application. We will start by presenting some of the options available at the planning and design stage, followed by an overview of some of the more critical parameters to be aware of when choosing subwoofer components. We will then describe the most popular enclosure designs to help you to determine which will be the best fit for your design goals. The implementation and set-up of your new subwoofer will also be discussed to ensure that you are able to maximize the potential of the new addition to your audio family.

DESIGN YOUR OWN

There are many resources available to the people of spirit, vision, wit, intelligence, and courage who choose to design and build their own subwoofer project. Some very popular books would include [500-021 "Designing, Building, and Testing Your Own Speaker Systems"](#) by David Weems, [500-034 "The Loudspeaker Design Cookbook VI"](#) by Vance Dickason, [500-037 "Bullock On Boxes"](#) by Roger Bullock, and [500-040 "Audio Amateur Loudspeaker Projects"](#) from Audio Amateur Magazine. These books present both theoretical and practical information that can be of great assistance to the pro sound subwoofer builder, although they do not discuss pro sound products exclusively.

Users who prefer a computer based design process will want to consider software programs like [500-923 "BassBox 6 Pro"](#) for Microsoft Windows, or [500-945 "Eminence Designer"](#), which is also Windows-based and is produced by the Eminence Loudspeaker Manufacturing Company. Eminence is one of the largest manufacturers of high quality speakers in the world and it would be safe to assume that they know a couple of things about speaker design!

Some speaker enthusiasts catch the bug and build speaker after speaker, trying different variations and refinements. Doctors are working around the clock, trying to find a cure for this disease. There are other audio do-it-yourselfers who take a more casual approach, completing a single project or occasional upgrade. These infrequent builders may not want to invest in a book library or software system, and we at Parts Express invite them to use our free design services. Our Technical Support staff can help with the selection of

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

speaker components, amplifiers, and cabinet accessories; more importantly we can provide customers with tuning and design information using the popular BassBox 6 Pro design software. There is a lot of information that is just a phone call or email away, don't be afraid to ask!

FOLLOW A PLAN

If you would like to embark on a subwoofer project, but would prefer to follow a proven path rather than blaze a new trail, you might want to consider following one of the many available speaker plans. Some of the excellent books previously mentioned include well thought out and easy to build plans that can speed your progress and help you to predict the outcome.

Many plans can be considered a place to start, and you can certainly make alterations or substitutions that suit your needs or your budget. If you do make changes, make sure that it is clear what effect your changes will have on the rest of the design.

Component selection

ACTIVE OR PASSIVE CROSSOVER

A crossover network for a subwoofer has the primary job of filtering out high frequency program that is above the intended operating range of the sub. This application is known as a low pass filter, also sometimes referred to as a high cut filter. As a matter of either convenience or system integration the low pass filter is sometimes combined with a second filter that removes low frequencies from the high range speakers. The name for that filter is a high pass filter (or low cut). Whatever bandpass we are shaping, there are two approaches to the application of these concepts. The most common approach is the passive network, which in various configurations is by far the most common for loudspeaker systems in general. A passive network refers to the use of high power handling capacity components AFTER the amplifier and before the speaker load itself. While there are some advantages as far as flexibility and cost, there are some significant downsides as well. The insertion loss that results from the inductive components lowers system efficiency, and passive filter circuits can also affect phase response, damping, and power handling.

An active network derives its name from the placement of the filter BEFORE the amplifier; the network is designed to operate at line level. The formulas that are used to calculate the crossover are similar in theory to the passive designs, but the voltage and current involved are obviously much lower. There is consequently much less of the

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

associated distortion and loss that we have described for the passive network, plus a few other significant advantages. Active crossovers send the filtered output to the amplifier responsible for each particular frequency range. Although there are cost, space, and complexity issues with using multiple amps, the advantages are improved headroom, lower distortion, and much greater control.

SUBWOOFER DRIVER SELECTION

The selection of the actual subwoofer driver must by necessity be considered throughout the process of choosing the actual type of enclosure. Each enclosure type can demand that a driver of a particular specification is used in order to provide the performance that is expected. In general, sealed box designs tend to expect a driver to have a relatively high Q_t s, low F_s s, very good x_{max} , and relatively soft suspension. Vented boxes will usually expect the driver to have a somewhat lower Q_t s, and remember that F_s s will need to also be fairly low since you cannot usually tune the box below that frequency. Horn loaded designs do not need a driver to have a low resonance because the length of the path of expansion, and the mouth area of the horn, determine low frequency cutoff.

A useful formula to determine the suitability of a particular driver for a particular box is the Equivalent Bandwidth Product (EBP), also known as the Equivalent Bandwidth Ratio (EBR). It is determined by taking the driver free air resonance (F_s) and dividing it by the electrical Q (Q_e s). If the resulting number is around 50 or less, you are looking at a driver that is best suited to a sealed type box. If the EBP is between 50 and around 100 or more, the speaker will work best in a vented enclosure. Horn loaded designs will perform best with an EBP of 150 or even higher.

Look closely at x_{max} values and any indicators of excursion limits for the driver that you are considering. The lowest musical octave that the subwoofer has to reproduce will cause far more stress than any higher frequencies. Linear long excursion capabilities combined with good cone control will provide high output low distortion sub bass. Most modern subwoofers will run out of mechanical power handling before they exceed their thermal power handling capacity.

Some users prefer to mount their subwoofer in a “down-firing” orientation. The cone mass of the driver must be taken into consideration, as the tendency for the cone to settle downward can move the voice coil out of the gap and affect x_{max} and excursion capabilities. As long as the amount of “sag” does not exceed 5% of x_{max} , the driver will work just fine in a horizontal configuration.

SINGLE OR DUAL VOICE COILS

A conventional woofer has a single voice coil that moves in the magnetic field and provides the motive force for the cone. A dual voice coil has a second coil wound concentrically with the first coil, and has its own separate terminations. The primary advantage of this arrangement is the ability of the dual voice coil subwoofer to accept

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

both left and right amplifier outputs in a single driver. This can be of obvious benefit in compact, low cost applications since bass is non-directional anyway. An alternative feature of the dual coil speaker is that choices can now be made to most effectively connect the subwoofer to the amplifier. If for example the dual coils are rated at 4 ohms each, you can decide whether to connect them in series (8 ohms) or parallel (2 ohms). This leads to even greater flexibility because the connected voice coil pairs can be connected to additional voice coil pairs to achieve a specific target impedance. For more on this subject, please go to our FAQ, or our driver wiring diagram page.

What do all these numbers mean?

Understanding the specs that matter...

When you begin to choose a loudspeaker component, you will soon begin to feel a little overwhelmed by the confusing and somewhat contradictory numbers and words thrown at you. For a quick overview of the specifications that matter the most for subwoofer selection, we will begin with the ones that are the most broadly applicable. When we get a little further along with discussing particular subwoofer box configurations, we will more thoroughly examine the parameters that affect those individual designs. Please feel free to jump over to our very comprehensive Technical Resources Page, and especially our Speaker FAQ Page, for more detailed explanations of some of these terms.

POWER HANDLING

The industry seems to have almost convinced us that power handling capacity is the most important number to consider when choosing speakers. High power handling is certainly a factor to consider, depending on your application, but be sure that you are looking at the right numbers. The RMS rating is based on a mathematical formula ($RMS = .707 \times \text{peak measured power}$) for determining average power that the speaker is subjected to, and it is usually a fairly conservative number compared to the continuous program power or peak power ratings that we will discuss in a moment. RMS ratings are only as good as the “qualifiers” that accompany them, for example, rating a hypothetical subwoofer at 600 watts/RMS doesn’t mean much if the frequency chosen for measurement (1000 Hz) is outside the range that you intend for the subwoofer to be used (25 to 125 Hz). In the case of this example, the power handling number would give us some idea of what the subwoofer could withstand in terms of thermal power handling capacity, but it would not reveal much about the mechanical limits at the lower frequencies where the subwoofer will be used. Lower frequencies require greater cone travel, and we will be expecting that subwoofer cone to be moving quite a bit! For the purpose of selecting a speaker it is useful to know the range of frequencies tested, or the single frequency if that is what was used. Since these qualifiers are sometimes a little hard to nail down, your best bet is to

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

stick with manufacturers that demonstrate the greatest credibility, and suppliers that take performance specifications seriously.

Continuous program power is generally understood to be double a given RMS rating, and tends to represent the kind of stress that a speaker is subjected to when that amount of music program is played through it. Although music can place dynamic stresses on a speaker, it also gives the components a chance to “rest” at intervals, even if those intervals are only a few milliseconds in duration. If you use a subwoofer rated at 200 watts RMS or 400 watts continuous program power, with an amp rated at 250 watts RMS, you are actually getting a pretty good match as long as the amp is not driven so hard that it exceeds its “clean” power rating of 250 watts RMS. When overdriven, the amp can exceed its RMS power rating and produce even more power, and that extra power will be loaded with a lot of harmful distortion.

Peak power is probably the least helpful rating for speakers. Any speaker can handle extremely high peaks of undistorted signal for milliseconds or microseconds, but these impressive numbers are rarely qualified by the disclosure of the test conditions that were used to determine them. In effect, peak power ratings are an example of a “numbers game” that marketing pressures have forced the manufacturers to compete in because higher numbers impress some buyers. The key to power handling ratings is reviewing and understanding the specifications that actually apply to the job at hand.

IMPEDANCE

Speaker impedance can be defined as the combined total of all resistance, inductance, and capacitance that the speaker presents to an amplifier. It is also referred to as “nominal impedance” because the actual number measured in ohms can vary quite a lot over the frequency range of the speaker. The actual nominal impedance value of 2, 4, 6, 8, or 16 ohms has no connection whatsoever with subwoofer performance or quality, but it is important for the proper match of an amplifier to the intended load. The lower the impedance value, the more power will flow through the speaker. If a 4 ohm and an 8 ohm speaker are connected to the same amplifier, the 4 ohm speaker will receive twice the power of the 8 ohm speaker, so matching values within the same frequency range can be pretty important. Multiple driver designs will require an awareness of the impedance of the intended drivers as various wiring configurations can increase or decrease the total value that the amp will see. It is also important to correctly identify subwoofer impedance as it is also a factor in establishing the values used to determine passive crossover components.

XMAX, EFFICIENCY, AND SENSITIVITY

Xmax is the term used to describe the linear excursion capability of a loudspeaker. It is basically determined by the length of the voice coil relative to the height of the magnetic gap of the speaker “motor”. The subwoofer can only provide clear, undistorted output if

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

the magnet is able to maintain control of the voice coil, and lower frequencies demand greater travel or excursion. The voice coil tends to have greater mass due to the increased amount of wire required for the longer surface area covered; this usually results in a reduction in higher frequency response, and lower overall driver efficiency.

Efficiency and sensitivity are very closely related. Efficiency is usually shown as a percentage that describes the ability of the speaker to convert an electrical input into an acoustical output. You will hear a lot of advertisements for speakers that declare the product to be “high efficiency”, but in fact that is a relative term.

Sensitivity ratings for loudspeaker products are representations of relative loudness, using a scale of decibels (dB), and with an input power of 1 watt (w). The resulting Sound Pressure Level (SPL) generated is typically measured at a distance of 1 meter (m) from the loudspeaker, so it would appear that we have everything we need to compare one speaker to another, right? Actually, it is just a start...

It is a surprising fact that loudspeakers in general and subwoofers in particular are very inefficient devices, electrically speaking. An “efficient” pro sound 12” midrange speaker with a sensitivity rating of 103 dB at one watt/one meter might have a reference efficiency of around 5 or 6%. This means that for all of the amplifier power going into the speaker, as much as 94% is wasted as heat and mechanical losses. Wait, it gets worse! Your state-of-the-art 18” subwoofer loudspeaker has a sensitivity of only 95 dB 1w/1m, or a reference efficiency of only 1.9%, so what good is that? Before you get mad at your speakers for being very expensive round heating elements, just relax and enjoy the benefits of modern technology! High performance amplifier power has gotten relatively cheap and reliable, and improvements with adhesives and high tech design have pushed speaker power handling to limits that could only have been dreamed of a generation ago. It was not that long ago that you were the king of the hill if your (probably tube) amp was cranking out a blazing 25 watts per channel, and your woofers (probably not subwoofers) were rated at 50 watts each. The high efficiency designs of that era were actually able to provide a very dynamic audio experience, but there are some alternatives for the contemporary user.

The most popular current thinking regarding efficiency relative to subwoofer output is to select a driver with a fairly high mass stiff cone, good linear excursion capability, and power handling that is high enough to withstand the power required to move that massive cone and long voice coil. This driver will have a fairly low sensitivity rating because of these design characteristics. In a properly designed enclosure, and driven by the appropriate amplifier, our example subwoofer will be able to deliver deep, clean, high impact bass.

We have established that power handling ratings are only relevant within a driver’s actual operating range; sensitivity ratings for a subwoofer only count in the sub-bass region below approximately 125 Hz. A subwoofer could actually have a response that is rising at frequencies that are outside the range that you intend for the sub to be used. The sound

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

pressure of these higher frequencies will affect a sensitivity rating if the manufacturer has averaged the boosted response of the higher frequencies with the reduced output that we would expect at lower frequencies.

FREQUENCY RESPONSE

The frequency response of a subwoofer is important but becomes far more meaningful when we are able to determine the actual response in the enclosure of our choice. As we have seen with other key specifications, frequency response numbers mean little without some kind of qualification. To simply state that a driver has a response “from 19 Hz to 1000 Hz” is leaving out critical information. If the relative output (remember SPL?) versus frequency is not disclosed, we could be looking at a response at 19 Hz that is 3, 6, or even 16 dB below the average response for the speaker. Similarly, there could be a 10 dB peak at 90 Hz. Frequency response graphs can be far more helpful, because the associated graph will display the variations in sound pressure level at any given frequency. Be sure to try to determine if the woofer shown on the graph was tested in an enclosure or free air, because free air plots will make the bass response look very puny indeed. Computer modeling programs like BassBox Pro can fill in a lot of information as far as what to expect for bass response from a given enclosure design. Keep in mind that since we are discussing subwoofers, the response of the driver above 125 or 150 Hz is not a matter of great importance to us.

Choosing a type of subwoofer, and adding it to your system

Learning that bigger is probably better

SEALED BOX

Sealed box subwoofer enclosures have advantages that appeal to beginners because of the simplicity of box design and construction, and to experts because of the compact enclosure dimensions, very good power handling, and outstanding transient response. They are noted for their tight “non-boomy” sound, and relatively small size compared to other designs. The driver will tend to have a fairly low free air resonance (F_s), long excursion capability (x_{max}), and loose suspension (the air loading of the small box provides restoring force). A bigger version of the contemporary compact sealed box is the classic “infinite baffle” which, because of the increased compliance of the air in the larger enclosure, requires a stiffer mechanical suspension to provide loading for the woofer cone. The larger cabinet volumes for infinite baffles are not always practical for all applications. All sealed box designs, large or small, tend to have lower sensitivity and higher bass roll off characteristics than other designs. They are used occasionally in pro sound applications, but their effectiveness is somewhat limited by the lack of efficiency.

VENTED BOX

Vented, ported, ducted, bass reflex; these terms all describe the same type of enclosure. Vented designs have been around for quite a while, but really came on with a bang after

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

acoustic researchers devised a way to effectively identify speaker parameters (the mechanical and acoustical characteristics of the driver in question) and use those parameters as elements in mathematical formulas that consistently model or predict the response of a given driver in a given enclosure. Simply put, the driver is matched to what is essentially a tuned resonant air chamber. As the driver goes lower in frequency, the driver excursion is reduced and the air in the vent proportionately increases its pressure on the air outside of the enclosure. This “high pressure air” in the port is just as effective a diaphragm at those frequencies as an actual hard diaphragm made of solid material. Talk about getting something for nothing! The vented box has a lot to offer, with advantages like flatter response down to the cutoff frequency or lower limit (although this is generally higher in frequency than a sealed box), reduced cone excursion near the box resonance frequency, and overall higher efficiency than most sealed box designs. There are also some significant limitations to this type of design. The transient response of the subwoofer is generally not as good as a sealed box design, but this can be minimized by careful driver selection and critical box tuning. Another problem is that there is no acoustic loading on the driver below the specific tuning frequency of the enclosure, meaning there is no control over cone motion beyond the subwoofer’s own mechanical suspension at those frequencies below the box resonance. This results in “bottoming out” and the ultimate destruction of the driver. A simple solution is to use a low cut or rumble filter before the amplifier to prevent the subsonic frequencies from affecting the speaker below cutoff. The overall design of a vented box can be a bit trickier for the casual speaker builder, but modern software programs like BassBox Pro or the technical support staff at Parts Express can help you to develop a high performance project. Vented designs have become the most widely employed style of subwoofer enclosure for pro sound applications, and can provide outstanding results as long as they are operated with some attention paid to the limitations that we have just mentioned.

PASSIVE RADIATORS

Passive radiators are an alternative to vented designs and are in fact part of the same family of enclosure design. It is the simple substitution of an actual diaphragm (usually similar to a speaker without a magnet and voice coil) for the virtual diaphragm of air in the vent that we just described in the last section. Advantages would include the absence of wind noises from a vent, and the ability to block higher frequency sound reflected from the back of the driver and out through the vent. They are also useful when a particular tuning requires a vent length longer than what the enclosure can accommodate. Some disadvantages are inferior transient response due to the actual mass of the passive radiator diaphragm, and greater difficulties in tuning compared to vented designs. Passive radiators still show up from time to time in sound reinforcement designs, but are far outnumbered by their vented cousins.

BANDPASS BOXES

Bandpass boxes are designs that use multiple chambers to create an acoustical filter that will focus and increase sound output within a specific frequency range. The most

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

common of the many variations is the 4th order bandpass, which consists of a woofer loaded in a conventional sealed box enclosure, but the output of the woofer is directed through a second vented chamber in front of the driver. The port increases gain in a fairly narrow range, but also acts as a low pass filter to help reduce high frequency output above the bass frequencies. The actual vent diameter should be as large as possible or practical, as these designs are particularly susceptible to vent noise- the whole output of the woofer is passing through that opening! Bandpass designs offer transient response approaching that of a conventional sealed box, combined with output that can actually be greater than a vented box. The downside of this family of boxes is a tendency toward an unnatural or “one note” sound, due to the peaky nature of their operating range. The bandpass box is slowly becoming more popular, as designers refine the tunings and employ electronic processing to correct the response.

TRANSMISSION LINES

The transmission line, or TL, is also known as an acoustic labyrinth because of the long and somewhat complicated path that the rear radiation of the speaker must pass through before exiting the enclosure. The idea is to use the long “tunnel” to selectively absorb higher bass frequencies through the use of damping material, while tuning the labyrinth length to equal a quarter wavelength of the resonant frequency of the driver. The rear pathway creates a 90 degree shift in the speaker’s rear radiation to constructively combine with the front radiation, while damping and controlling cone motion at the driver’s resonant peak. There are many variations on the basic TL concept, but not as much data to mathematically model or predict the performance of a particular design compared to closed box or vented systems. The concept demands especially careful analysis of loudspeaker parameters, a fair bit of testing and tuning, and the space to accommodate a design that may turn out to be somewhat large and heavy. TLs are extremely rare in pro sound applications due to their complexity and weight.

HORN LOADED

If we looked back through the mists of time, we would see small power amplifiers and low wattage speakers requiring a little bit of a lift from the Laws of Physics to get the kind of sound pressure level demanded by many playback environments. The use of horns to boost audio output certainly became very popular during that era, and horns still have a place in some specific modern audio applications. If you have ever cupped your hands in front of your mouth to amplify your own voice (“Hey, you kids, cut that out!”) you will have employed basic horn loading techniques. Horns increase the gain or output of a source, and also improve its directivity or directionality. The horn serves as a transformer that matches the high acoustical impedance or pressure presented by the driver at the small throat of the horn to the lower acoustical impedance seen by the air at the larger mouth of the horn. Linearity is maintained by a carefully calculated “flare rate” for the horn path that ensures that the sound will travel with consistent expansion. The overall directivity and low frequency response of the horn are both determined by the length and mouth area of the horn. A large low frequency horn can be made smaller by

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

“folding” it, which can get some of the larger designs down to a more manageable shape and size. Although horns have many attributes including high efficiency, excellent transient response, and great dispersion control, their size and complexity tends to make them an impractical choice for smaller scale applications.

BASS ACTUATORS

The small but mighty bass actuator does not require an enclosure of any kind, but still has a place in our general discussion concerning sub bass performance. A bass actuator is a small servo device or motor that converts an audio input signal into a mechanical force that is placed in direct contact with a solid surface. Conventional subwoofers transmit information through air, while an actuator delivers low frequency program directly through solids. The sensation is very much the same as it would be if the sub bass had come from a speaker first and then vibrated the solid surface, so actuators can be useful in situations where space is too limited for large speaker enclosures. The density or construction of the object to which the actuator is attached will place limits on the intensity and coverage of the effect. The bass actuator has a place in a pro sound subwoofer discussion because of a specific application for the device in stage monitoring applications. Some drummers require very loud monitor speakers to enable them to hear themselves or the other musicians. In an effort to get away from the “Texas headphone” dual stacks of large monitor speakers, some pro sound providers have installed bass actuators on the drummer’s throne. This reduces the excessive noise spill that larger stage monitors produce, while still delivering a sub bass punch that the drummer can feel.

Putting it all together

Five minutes until showtime, and the paint is still wet...

CABINET SHAPES

Modern analysis seems to suggest that special cabinet dimension ratios do not have as much of an effect on performance as what was once assumed. Standing waves are caused by the reflection of frequency wavelengths that happen to be the same size as the distance between parallel surfaces, or surfaces that are at right angles to the first surface and of the same size. This effect can be minimized by using enclosure designs with non-parallel panels, or using proportions that can reduce the opportunities for the offending frequencies to reinforce themselves. The generally accepted “golden ratio” for these proportions is said to be 2.6/1.6/1, but the use of this ratio is not critically important when designing and building subwoofers. The trapezoidal shape that is so common for the ease of creating mid/high arrays is also helpful for subwoofer box enclosures because of the non-parallel sides, but the sub box can work just fine if it has a more traditional shape. An airtight box, well braced, and adequately stuffed with damping material, will be as important as the shape of the enclosure. A subwoofer enclosure has to conform to the dimensional and/or transportability issues mentioned in the introduction to this

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

discussion, and even built in subs face constraints imposed on them by the structure into which they are built.

CABINET MATERIALS AND CONSTRUCTION TECHNIQUES

The material of choice for subwoofer enclosures designed for permanent installation is MDF or medium density fiberboard. It has greater mass and density than particle board, which comes in second due to the use of larger particles or flakes of wood in its composition and lower glue content. Void free birch plywood is more appropriate for portable speakers because it is stronger and lighter than composition products, but unfortunately is not as dense. An airtight enclosure with well braced and damped panels will ensure that more sound energy reaches the listener instead of simply vibrating the cabinet walls or pushing the air out of small gaps. The use of a silicone or latex caulk should be used for all cabinet joints and even input terminals, no matter how solid things seem to be. Speaker sealing caulk or foam tape are convenient products that can ensure that the driver's mounting will not contribute to leaks. Special care should also be given to the grill cloth or screen that many users install to prevent the exposure of the driver to dust or foreign objects. The excursion limits of the subwoofer can be quite considerable and could exceed the clearances provided by some methods of protection, resulting in buzzes, rattles, or even damage to the driver.

The finishing of the enclosure is as important to some users as the actual acoustical performance of the subwoofer system. Popular finishes include genuine wood veneer, simulated wood laminates, or paint for permanently installed enclosures, and paint, carpet, fiberglass, or even spray on/roll on truck bed liner for portable boxes. Each has its own advantages and disadvantages, but it is probably one of the most subjective decisions that will be made during the whole subwoofer project. The one that you like the most or feel most comfortable applying is the best one for your project, as exterior finish will have little noticeable effect on subwoofer system acoustical performance. The actual conditions of operation that the subwoofer is exposed to, or the environment in which it is used, will tend to help you to determine the most appropriate cabinet exterior treatment.

What will have a serious effect on performance is stuffing. Stuffing, or filling, is used primarily to absorb or minimize standing wave reflections within the box. The proper use of stuffing can also affect the virtual box size that the subwoofer "sees" and can provide an increase in effective volume of 25% or more. This can be useful for applications where the enclosure size is marginally smaller than optimum, or to make up for internal volume losses from driver or brace displacements. Fiberglass, Dacron, Acousta-Stuf, acoustic foam, and long fiber wool are all popular and readily available acoustic damping materials. Portable speakers will require extra effort to ensure that your chosen insulation stays in position because of the extra motion and vibration that occur during travel. Be sure to identify the basic stuffing requirements or recommendations for your chosen project, but consider those to be a suggested starting point. Experimentation can lead to an amount of filling somewhat greater or smaller than originally specified, but can result in performance that satisfies the user's personal requirements.

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

Placement, set-up, integration, tweaking

Sure, it's heavy, but what does it sound like?

The sawdust has settled, there are still a few splinters under your fingernails, and you can always put the tools away later, really. It's time to make that box jump off the floor. The non-directional nature of bass has already been discussed, and you will recall that specific room placement of the subwoofer is not as critical as other speakers in your system. It is also true, however, that combining subwoofer cabinets into larger arrays can begin to control the dispersion or directivity of even the sub bass frequencies. We also touched on the subject of standing waves inside the speaker enclosure; it shouldn't surprise us that we will need to address standing waves in the listening space as well. Bass energy is easily reinforced by reflection, and as those reflections recombine, the resulting buildup can cause very irregular response in the room in the form of peaks. Similarly, phase cancellations can occur when the sound waves at a specific frequency cause destructive interference and cancel each other out, and create holes or nulls in the response. The common "split stack" arrangement of dividing speakers on either side of an event stage offers easy deployment and reasonable coverage, but will also present opportunities for the frequency response to have significant peaks and dips due to standing waves and phase cancellation. One possible solution to control phase cancellation at bass frequencies is to place the subwoofers together at the front of the stage as a single array. Unfortunately, lining up the cabinets in a long horizontal row will actually narrow the dispersion in that axis and create a "power alley" effect of strong bass in the middle, but not to the left or right. If the split stack configuration must be used, try to stack the subwoofers vertically if possible, or in 2x2 blocks. If the mid/high speakers are suspended overhead and the subs stay on the ground, some attempt should be made to preserve a consistent front-to-back relationship between all speakers in the array. Keeping the subwoofers in alignment along a line drawn between the left/right main speakers and also in the vertical plane will help to keep the speakers in the same time domain (yes, a foot or two can matter here!) and will improve coherence. If the optimum physical placement cannot be achieved, many electronic crossover networks and digital system processors offer onboard time delay compensation to bring the system into correct alignment.

When properly integrated, the actual location of the subwoofer will disappear and the bass will seem to be coming from the mid/high speakers in the system. Test tones and measurement equipment can help you with your system setup, but good results can also be achieved by spending time with a couple of well recorded CDs with which you are especially familiar. An open microphone will help you to identify sub bass frequencies that are peaked enough to cause feedback. Sometimes a microphone located on a resonant stage can be sensitive to the mechanical transfer of sound energy instead of the expected acoustical path. "Shock mount" microphone holders can help to minimize this effect, as can active low cut filters on mixers or equalizers. You may find it useful to have an associate make adjustments to the various system controls, or even move speaker

BUILDING YOUR OWN PRO SOUND SUBWOOFERS

PRESENTED BY PARTS EXPRESS

725 Pleasant Valley Dr. Springboro, OH 45066-1158 1-800-338-0531 www.PartsExpress.com

enclosures, while you remain in a consistent listening position. After satisfying yourself that your primary location is OK, move around a bit to make sure that the wider soundstage is acceptable. Now, on with the show!